

Smart Facility management (SFM)
10 Anson Road, #22-02 International Plaza, Singapore 079903
URL:http://www.smartdigitalbuild360.com/

M & EINSPECTION FORM - Mechanical (Monthly)

ANNEX D7_1

SITE: HDB Project1 15 Cedar Avenue, Singapore-349700

Month: February 2021

S/N	ITEM	DONE? (Yor Nor NA)	Date Done	Remarks
1	SERVICING, INSPECTION AND TESTING OF AIR CONDITIONING M /DUCTED FCU / VRV / VRF)	ECHANICAL VENTILATION (ACMV) SYSTEM (SI	INGLE-SPLIT / MU	ILTI-SPLIT / AHU / PACKAGE UNIT
1	Clean evaporator coil and drip tray and flush drain pipe with approved solution	▼ Yes □ No □ N/A	03/06/2021	
2	Check Fresh Air Intake System and clean/replace filters (including HEPA)	✓ Yes ☐ No ☐ N/A	03/06/2021	
3	Inspect and clean air filter at the Fan Coil Units. Replace if necessary	Yes No NA	03/06/2021	
4	Check for refrigerant leaks in system, recharge gas if necessary	✓ Yes 🗌 No 🔲 N/A	03/06/2021	
5	Check and comb all dented fins of coils	✓ Yes No No NA	03/06/2021	
6	Check and clean electrical contacts and tighten all screws	Yes No No NA	03/06/2021	
7	Check routine operation of electrical components in control panel. Check and replace all blown fuses, indicating bulbs as specified if applicable	✓ Yes ☐ No ☐ N/A	03/06/2021	
8	Check all anti vibration isolators for deterioration, replace if necessary	▼ Yes No NA	03/06/2021	
9	Clean, wire brush, touch up and paint all rusty parts	Yes No No NA	03/06/2021	
10	AHU: Check Blower for unusual sound, make good Blower by rectification on the cause of the unusual sound	✓ Yes No No NA	03/06/2021	
11	AHU: Wash all washable filters and replace with new when found damaged/deteriorated beyond reuse	▼ Yes □ No □ N/A	03/06/2021	
12	AHU: Check and Test Duct Smoke Detector and ensure its correct operation	Yes No No NA	03/06/2021	
13	To take Refrigerant pressure reading for the Supply and Discharge pipes, top-up refrigerant gas when insufficient for the AC to operate effectively (to attach spreadsheet)	Yes No NA	03/06/2021	
14	AHU: Check condition of duct insulation and to re-tape loosen insulation with aluminium tape. To report damaged insulation work and any signs of condensation	Yes No NA	03/06/2021	
15	AHU: Clean up the plant room and clear choke in floor trap	Yes No No NA	03/06/2021	
16	Replace deteriorated/missing pipe insulations	Yes No No NA	03/06/2021	
17	Check changeover of compressor, if any	Yes No No NA	03/06/2021	
18	Check piping joint connections for leak, if AC often require gas top-up	Yes No No NA	03/06/2021	
19	Check for abnormal running noise (Condensing Unit)	Yes No NA	03/06/2021	
20	Check compressor oil level, top up if necessary (applicable to open type compressor only)	Yes No NA	03/06/2021	
2	SERVICING, INSPECTION AND TESTING OF PUMPING SYSTEMS (PUMPS/ PORTABLE PUMPS/ SUMP PUMPS/ EJECTOR PUMPS/ STPUMPS ETC)			
1	To check Pressure Switch Cut-IN/OUT pressure chart is displayed, if found missing or damaged, replace with new display.	Yes No NA	03/06/2021	
2	To confirm pump Out-IN/OUT is as accordance to design criteria (ref Out-IN/OUT pressure chart).	Yes No NA	03/06/2021	
3	To listen for abnormal sound from pump bearings locations	Yes No NA	03/06/2021	
4	To listen and observe for abnormal sound from pump housing	Yes No No NA	03/06/2021	
5	To observe the pump for excessive vibration	Yes No No NA	03/06/2021	
6	Check drive shaft is free to turn by turning at the motor-pump shaft coupling	Yes No NA	03/06/2021	
7	,	Yes No No NA	03/06/2021	
8	Check electrical control panel and remote indicating panel for loose termination and proper operation of all electrical components	Yes No NA	03/06/2021	
9	Check anti-vibration mountings and tighten holding down bolts, clamps etc	Yes No NA	03/06/2021	
10	Re-calibrate Pressure Switch setting accordingly as stated in the CUT-IN/OUT label	Yes No NA	03/06/2021	
11	Check for leakages	▼ Yes □ No □ N/A	03/06/2021	
12	Touch-up paint to all metal corrosion/rusty portion	✓ Yes ☐ No ☐ N/A	03/06/2021	
13	Test all Alarm status by simulation through the control panel for Tank Overflow and Power failure	Yes No NA	03/06/2021	
14	SUMP PUMP: Clean and clear debris, sand and silt from pump sump pit if applicable	Yes No NA	03/06/2021	
15	Check the system operation and control including the auto-change over operation of pump	Yes No NA	03/06/2021	
16	TRANSFER PUMP: Check the functioning of the water level control system	Yes No NA	03/06/2021	

S/N	ITEM	DONE? (Y or N or NA)	Date Done	Remarks
17	Pressure Vessel - Check air pressure in tank, where applicable. Charge air pressure to tank if insufficient (according to manufacturer spec) To record reading	Yes No No NA	03/06/2021	
18	Level Switches - Check operation of water tank float valve and all level switches and rectify (if necessary).	✓ Yes 🗌 No 🦳 N/A	03/06/2021	
3	SERVICING, INSPECTION AND TESTING OF AUTOMATIC OR MOTI SHUTTER SYSTEM	ORISED GATES/ ROLLER SHUTTER/ DOOR:	S/ LOUVRES/ SMOKE	CURTAIN SYSTEM AND FIRE
1	Lubricate all gears, ripples and chains, when needed	✓ Yes No No NA	03/06/2021	
2	Check close and open cycle for smooth operation	✓ Yes ☐ No ☐ N/A	03/06/2021	
3	Check and clean floor guides/floor track	▼ Yes □ No □ N/A	03/06/2021	
4	Check the track wheels/rollers, gear/pulley/pivot and chains for wear and tear	✓ Yes No NA	03/06/2021	
5	Check micro-switches/magnetic/timber for proper operations	▼ Yes No NA	03/06/2021	
6	Check stopper bracket and pelmet; tighten if necessary	▼ Yes □ No □ N/A	03/06/2021	
7	Check the rubber bumper and door alignment	✓ Yes No NA	03/06/2021	
8	Check relays/actuation devices are working properly		03/06/2021	
	Test for proper operation on the panic opening, lock and sensors,	Yes No NA		
9	repair and replace when necessary Check counter balance of the barrier arm and adjust the spring	Yes No NA	03/06/2021	
10	tension when necessary	Yes No No NA	03/06/2021	
	SERVICING, INSPECTION, CLEANING AND TESTING OF FRESHAIF LABORATORIES)	R INTAKE SYSTEM AND EXHAUST SYSTEM	I (INCLUDE BUT NOT I	LIMITED TO CANTEEN, TOILETS AND
1	Inspect and clean Fresh Air Fan and filter (if any). Replace filter when it is no longer serviceable	✓ Yes ☐ No ☐ N/A	03/06/2021	
2	Inspect and clean grease filters	▼ Yes □ No □ N/A	03/06/2021	
3	Clean electrical contacts and tighten all contacts	▼ Yes □ No □ N/A	03/06/2021	
4	Check all anti vibration isolators and housing	✓ Yes No NA	03/06/2021	
5	Clean, wire brush, touch up and paint all rusty parts		03/06/2021	
		Yes No NA	_	
6 7	Check for damaged, wrong or missing labels and replace Check and rectify or replace faulty components and connections in	Yes No NA	03/06/2021	
	the control panel	Yes No NA		
8	Test runs the whole system for proper operation	Yes No No NA	03/06/2021	
9	Check Panel and PLC module are linked and in proper operation	Yes No NA	03/06/2021	
10	Kitchen Exhaust Fan: Check for Duct Joint Section for leakages	Yes No No NA	03/06/2021	
5	SERVICING, INSPECTION AND TESTING OF SYNTHETIC FIELD WA	TER SPRINKLER SYSTEM		
1	Turn on water supply. Pressurize system, check for leaks on the backflow and in the system. Check rain sensor. Program controller for proper seasonal conditions	▼ Yes □ No □ N/A	03/06/2021	
2	Turn off water supply. Drain back supply line. Blow out all zones. Winterize backflow preventer SERVICING OF STORMWATER DETENTION TANK SYSTEM	Yes No No NA	03/06/2021	
1	To desilt and clean the detention tank, trash screens	✓ Yes No NA	03/06/2021	
	To servicing and testing the pumps, pump starters and the	E LES E INO E INA	00/00/2021	
2	instrumentation and control systems and servicing the standby generator.	Yes No No N/A	03/06/2021	
7	SERVICING & INSPECTION OF CLEAN AGENT FIRE SUPPRESSION			
1	Check interface with fire alarm system.	Yes No No NA	03/06/2021	
2	Check interlock with ACMV dampers.	Yes No No NA	03/06/2021	
8	SERVICING & INSPECTION OF AUTOMATIC FIRE SCANNING WATE Water Monitor Device	ER MONITORING SYSTEM (FIRE MONITOR S	SYSTEM)	
1	Conduct a dry test using a 500mm x 500mm size fire on Water Monitor Unit and confirm that the internal sensors are operating	✓ Yes No No NA	03/06/2021	
2	normally. Check that the nozzle is directed accurately at the fire source.	✓ Yes No NA	03/06/2021	
3	Visually inspect the condition of components,	Yes No NA	03/06/2021	
	Manual Override Control Panel	F 165 NO E IVA	00/00/2021	
4	Check that all controls are working normally in 'OVERRIDE' mode.	✓ Yes No No NA	03/06/2021	
5	Check all cable connections in the panel.	Yes No NA	03/06/2021	
6	Check all indicating lights.	Yes No NA	03/06/2021	
9	SERVICING & INSPECTION OF AUTOMATIC IRRIGATION SYSTEM			
1	Inspect the controller and make sure it is plugged in and functioning.	✓ Yes 🗌 No 🔲 N/A	03/06/2021	
2	Update the date and time.	Yes No NA	03/06/2021	
3	Check the connection on all the wires - make sure that the rain, wind, or soil moisture sensors are connected.	Yes No NA	03/06/2021	
4	Replace the backup battery.	✓ Yes 🗌 No 🔲 N/A	03/06/2021	
5	Turn on each zone and look for system damage.	✓ Yes No No NA	03/06/2021	
6	Turn on and run numna and nmarum vaccala	Yes No NA	03/06/2021	
	Turn on and run pumps and pressure vessels.	W 165 L NO L NA	03/00/2021	
5 6 9	Check that all controls are working normally in 'OVERRIDE' mode. Check all cable connections in the panel. Check all indicating lights. SERVICING & INSPECTION OF AUTOMATIC IRRIGATION SYSTEM	✓ Yes No No NA ✓ Yes No No NA ✓ Yes No No NA	03/06/2021 03/06/2021	

Checked By

d--

(Testing)
THE CONTRACTOR
Date: 04/06/2021

Remarks:

Endorsed By

132

(User) USER

Date: 04/06/2021

Remarks:

Verified By

(saravanan)

MANAGEMENT AGENT

Date: 11/06/2021

Remarks: