

MKV ENGINEERING AND TRADING SERVICES PTE LTD

NO : 10 KAKI BUKIT ROAD 1 #03-12 KB INDUSTRIAL BUILDING SINGAPORE - 416175 TEL: 6283 9289 FAX: 6283 9286 Email: info@mkv.com.sg

M & E INSPECTION FORM - Electrical(Quarterly)

ANNEX D7_2

Month: September 2019

SITE: Gan Eng Seng Primary School 100, Redhill Close, Singapore 158901

S/N	ITEM	DONE? (Y or N or NA)	Date Done	Remarks
1	FAN SYSTEM			
1	Check fan speeds are operated according to the fan regulator setting, replace regulator if faulty.	✓ Yes ☐ No ☐ N/A	04/09/2019	
2	Check for wobbling & speed. The condition of the fan blades, motor holding bolt, and plastic sleeve. If found any of the mentioned parts that are not in-order, isolate fan and replace with new spare part.	▼ Yes □ No □ N/A	04/09/2019	
2	LIGHT SYSTEM			
1	Check cover/housing has no discoloration or cracks and supports are secured, replace if necessary.	✓ Yes ☐ No ☐ N/A	04/09/2019	
2	Check and all bulbs/tubes including LED drivers and lights are in working conditions, rectify or replace if necessary. To report to School any non-functioning lights.	▼ Yes □ No □ N/A	04/09/2019	
3	UNDER FLOOR / RAISED FLOOR TRUNKING			
1	Check the cover and internal free from obstruction. Replace cover when necessary.	✓ Yes ☐ No ☐ N/A	04/09/2019	
2	Check all connections and cabling condition.	✓ Yes ☐ No ☐ N/A	04/09/2019	
3	Check and replace seal when necessary	✓ Yes □ No □ N/A	04/09/2019	
4	HAND DRYERS/BLOWERS/ HAIR DRYERS/V	VATER HEATERS		
1	Check and ensure that the systems are working.	✓ Yes ☐ No ☐ N/A	04/09/2019	
2	Check and tighten all the mechanical mounting.	✓ Yes ☐ No ☐ N/A	04/09/2019	
5	SERVICING AND INSPECTION OF LIGHTNING		NING WARN	ING SYSTEM
1	Contractor to refill earth pit with sand to brim of pit if the As and when level of sand is found to be below brim.	✓ Yes ☐ No ☐ N/A	04/09/2019	
2	To check and verify that the Pit Cover is easily open and close neatly	▼ Yes □ No □ N/A	04/09/2019	
3	To check and verify Earth Pit Assembly is flushed with the surrounding surface	▼ Yes □ No □ N/A	04/09/2019	
6	SERVICING, INSPECTION AND TESTING OF		1 1 1 1 1	1. (1. 6.11.)
	The servicing and maintenance work of the stag	ge lighting and system shall include	e but not limit	ed to the following :-
1	i. Maintenance (including cleaning, repair and replacement) of the system including all bulbs, console unit (control panel), dimmers, fixture & fittings etc.	✓ Yes ☐ No ☐ N/A	04/09/2019	
2	ii. Response to faults as directed.	✓ Yes □ No □ N/A	04/09/2019	
3	iii. Replacement of damaged, blown or faulty bulbs complete with wires and fuses, holders where necessary.	✓ Yes ☐ No ☐ N/A	04/09/2019	
4	iv. Rectify unusual noise or vibration.	✓ Yes ☐ No ☐ N/A	04/09/2019	
7	SERVICING, INSPECTION AND TESTING OF	MATV SYSTEM		
1	To check antenna in good condition, no damage or defective parts	✓ Yes ☐ No ☐ N/A	04/09/2019	
2	To check connectivity within the Site.	✓ Yes ☐ No ☐ N/A	04/09/2019	
8	SERVICING, INSPECTION AND TESTING OF	SOLAR HEATERS		
1	Wash the glass cover of the collector with clean water	✓ Yes ☐ No ☐ N/A	04/09/2019	
2	Check heater element in working condition	✓ Yes ☐ No ☐ N/A	04/09/2019	

S/N	ITEM	DONE? (Y or N or NA)	Date Done	Remarks
	Inspect storage tank and ensure cover for electrical booster is properly fixed to ensure no rainwater enters into the electrical component	✓ Yes ☐ No ☐ N/A	04/09/2019	
4	Inspect pressure / temperature relief valve on the tank. Quarterly The valve easing lever shall be operated for several short periods to discharge hot water and pressure from the tank. Ensure lever when release will return to normal position and no leakage of water from the valve	☑ Yes ☐ No ☐ N/A	04/09/2019	
	General inspection of pipes, valves to ensure that there is no leakage	✓ Yes ☐ No ☐ N/A	04/09/2019	
9	SERVICING, INSPECTION AND TESTING OF INDUCTION HEARING AID		M & FREQU	ENCY MODULATION (FM)/
1	All the handsets/hearing sets shall be checked, serviced and replaced when necessary.		04/09/2019	
10	SERVICING & INSPECTION OF 2-WAY VOICE SYSTEM		JLUDUNG F	REMAN TELEPHONE
	All the handsets/hearing sets shall be checked, serviced and replaced when necessary.		04/09/2019	
3	Check recording system including controls. Simulate operation. fire alarm condition and	✓ Yes ☐ No ☐ N/A ✓ Yes ☐ No ☐ N/A	04/09/2019	
4	check system. Inspect and test the system prescribed in SS 546 Emergency Voice Communication	✓ Yes ☐ No ☐ N/A	04/09/2019	
11	Systems in Buildings. QUARTERLY SERVICING, INSPECTION AND	TESTING OF HIGH TENSION FI	ECTDICAL I	NSTALL ATIONS
1	Vacuuming and cleaning of the switch rooms and transformer rooms including removing accumulated water from cable chambers, trenches, etc.	✓ Yes ☐ No ☐ N/A	04/09/2019	NOTALLATIONO
2	Inspect faulty lighting and power points.	✓ Yes ☐ No ☐ N/A	04/09/2019	
<u> </u>	Inspect for leakage and cracks in floors, walls and ceilings.	✓ Yes ☐ No ☐ N/A	04/09/2019	
4	Inspect operation of dehumidifiers and room ventilation.	✓ Yes ☐ No ☐ N/A	04/09/2019	
5	Replace defaced, damaged or missing "DANGER" signs.	✓ Yes ☐ No ☐ N/A	04/09/2019	
6	Check all switch room and transformer room doors and locks.	✓ Yes ☐ No ☐ N/A	04/09/2019	
,	Check condition of meter box and rectify as necessary a. Voltage of incoming breakers and all outgoing breakers for outgoing breakers with voltmeters. b. Current of incoming breakers and all outgoing breakers for outgoing breakers with ammeters.	▼ Yes □ No □ N/A	04/09/2019	
	Check the status of all the incoming and outgoing breakers.	✓ Yes ☐ No ☐ N/A	04/09/2019	
9	Conduct checks for the following: a. Signs of corrosion of switchboards and transformers. b. Unusual smell which indicates overheating. c. Unusual noise indicating wrong discharge. d. Replace any blown indicating bulbs and to replace other small parts on the switchboards which are faulty. e. Replace rubber mats which are torn or in a deteriorated condition.	☑ Yes □ No □ N/A	04/09/2019	
10	Inspect the DC supply system for the HT switchgears for the following (where applicable): a. Top up the electrolyte level of the battery cells. b. Check and record the charging current and voltages of the battery charger. c. Record temperature of individual cell electrolyte. d. Check battery cell, plates, etc. for any abnormality, etc. e. Clean battery terminals thoroughly and apply fresh petroleum jelly.	▼ Yes □ No □ N/A	04/09/2019	

S/N	ITEM	DONE? (Y or N or NA)	Date Done	Remarks
11	Inspect the following for the transformers: a. Record the readings of the oil temperature and level. b. Record the readings of the oil pressure gauge. c. Tank, radiators, auxiliary equipment and other metal parts for corrosion, abnormalities, etc.	▼ Yes □ No □ N/A	04/09/2019	
12	SERVICING & INSPECTION OF CCTV SYSTE Camera Lens	:M (MK and KCARE)		
	Check the camera lens is focused and adjusted properly.	✓ Yes □ No □ N/A	04/09/2019	
2	Check the camera view hasn't been knocked off path and you can see your property perimeter clearly	✓ Yes ☐ No ☐ N/A	04/09/2019	
	Clean any dust or marks off the camera lens with a can of compressed air and wipe down the camera casing with a microfibre cloth	✓ Yes ☐ No ☐ N/A	04/09/2019	
	Check that the motion detection sensors are working, if you have them	▼ Yes □ No □ N/A	04/09/2019	
5	Use your controller to check that the camera's functions, such as zoom and pan are working correctly	✓ Yes ☐ No ☐ N/A	04/09/2019	
0	Trim back any foliage that may be obscuring the view	✓ Yes ☐ No ☐ N/A	04/09/2019	
7	Check that the cameras are securely attached to the wall	✓ Yes ☐ No ☐ N/A	04/09/2019	
	Wiring			
_ ^	Check wiring for any wear and tear or exposed wires	▼ Yes □ No □ N/A	04/09/2019	
9	Check for loose wires	✓ Yes ☐ No ☐ N/A	04/09/2019	
10	Check that you're getting a clear transmission of sound (where applicable) and picture with no distortion	✓ Yes ☐ No ☐ N/A	04/09/2019	
	Monitors and recording equipment			
	Check that the monitors are showing a clear picture and that the brightness and contrast settings are correctly adjusted	✓ Yes ☐ No ☐ N/A	04/09/2019	
12	Check all switches and individual equipment are functioning fully	✓ Yes ☐ No ☐ N/A	04/09/2019	
	Clean all monitors and equipment of dust and grime with a microfibre cloth and a weak cleaning solution	✓ Yes ☐ No ☐ N/A	04/09/2019	
14	Check cables leading from the equipment are in good condition and that there are no weak connections	✓ Yes ☐ No ☐ N/A	04/09/2019	
าเอ	Check that the correct time and date stamp is set	✓ Yes ☐ No ☐ N/A	04/09/2019	
Checked By Verified		d Ву	Endorsed	I Ву
			- The state of the	
(sdfsdfds) (zdfsdf) (dsfdsgfd)				

THE CONTRACTOR Date: 04/09/2019

MANAGEMENT AGENT

Date: 04/09/2019

USER

Date: 04/09/2019